

INSTALLATION OF STEALTH ACCESS PANELS BY WIND WIND-LOCK® RETROFIT CONSTRUCTION

- When installing a Standard Stealth Panel, make sure the frame and the door remain together. If you need to separate the panel from the frame, be sure to mark it to match the frame it came with and store in a safe area.
- When installing a Round Stealth Panel, be sure the door is in the frame during installation or above the frame while installing. The door will not fit into the frame once the drywall is in place.
- When storing the panels, be sure they are all stored vertically in a safe, cool, dry place.



Stealth Access Panel Basic Installation Guide



Stealth Access Panel Basic Installation Guide



Stealth Access Panel Basic Installation Guide



Stealth Access Panel Basic Installation Guide



Stealth Access Panel Basic Installation Guide



Stealth Access Panel Basic Installation Guide



Stealth Access Panel Basic Installation Guide



Stealth Access Panel Basic Installation Guide

